


Battery Installation:


1. Remove the battery covet of the remote control, install two new 7#batteries.



2. Install the battery cover. The time will appear in the left corner of LCD display

Product Introduction

Model K-1028E All-purpose Air Conditioner Remote Controller has been designed to remotely control various brands and models of the air conditioners. This product's characteristic of point-to-point fast brand searching and automatic digital code searching with low power consumption, complete functions, long transmission distance, easy setting, simple operation and fresh visual appearance and comfortable hand feel which can facilitate you with unlimited convenience. The product has a large LCD screen which provides easy setting and operation. It has built-in clock, on/off timer and night illumination function which have facilitated more convenience for you.



1. Signal Sending Display
2. Fan Display
3. Blowing Direction Display
4. Backlight
5. Temperature " + " key
6. Mode key
7. Automatic Blowing Direction Control Key
8. Blowing Direction Control Key
9. Timing OFF Key
10. Timing ON Key
11. SET
12. Clock Function Key
13. Run Mode Display
14. Temperature Display
15. Model Code
16. Power Key
17. Fan Key
18. Temperature " - " key
19. Fast Cool Key
20. Fast Heat Key
21. Confirmation Button

Remarks:

Completion key

Fast Cool/Heat Key

- Press "Fast Cool" key to automatically set the machine as refrigerating mode, 21°C, middle wind, automatic blowing direction
- Press "Fast Heat" key to automatically set the machine as heating mode, 27°C, middle wind, automatic blowing direction.


*In "Fast Heat" mode, press "EA Heating" key to enter EA Heating mode

Setting of Remote Control

This remote controller has four setting modes that are marked as A, B, C and D. Please select one mode for operation.

A The brand corresponding point-to-point fast searching

1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.



2. Press the code key that corresponds to your brand and hold until the air conditioner is started by giving out a sound signal. Release the key and the setting is completed.




Table of brand corresponding keys


ON/OFF	TEMP	TEMP	WIND	MODE	M. SWING
GREE / Haier	MDTOS-BA QIANG-CHONG	SHARP \ KE LONG	MITSUBISHI /OTHER	LG \ SAMSUNG	HITACHI \ Panasonic
A.SWING	Timing	Timing	Fast cooling	Fast heat	
SANYO \ HISENSE	CHIGO \ DAIKIN	FUJITSU \ GARRIER	CHUNLAN /AUX	SHINCO \ AUCMA	

B Manually input code


1. Manually plug-in the air conditioner, find the type of the air conditioner in the "Code Table", and find the first code, for example: Haier

BRAND	CODE
HAIER	001-019


2. Hold SET button (for about three seconds) until the conditioner type code flickers in the window, press Temperature "▲" or "▼" buttons until the desired code flickers in the window. When the code is right, the air conditioner will start.



3. Press OK button and the selected conditioner type code will stop flickering.




4. Test whether the remote control button has been effectively set. If yes, setting completes. And if no, repeat steps 2-3.




C Digital automatic search type

1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.




2. Hold SET button (for about six seconds) until the conditioner type code changes in the window, indicating you have entered the high-speed conditioner type search status. press OK button to stop searching until the air conditioner automatically starts.




3

Test whether the functions of remote control buttons (excluding Temperature and buttons, timed ON/OFF buttons, and SET button) are correct. If yes, the code is effectively set. If not, press SET button to continue once the search



Set Time Function

Press CLOCK button (for three seconds) to enter the clock setting status, and the clock will flicker. Use the Temperature "▲" or "▼" buttons to adjust the current time, and press CLOCK button again to exit setting.



Timing ON/OFF Function

To configure the timer function of the original remote control, press TIME ON or TIME OFF buttons, and the air conditioner timer lights will go on, indicating the air conditioner has entered the timed status

※ The timed ON function of some of the air conditioner types is only valid only in the Power Off status

Warm Tips:



This remote control is effective if the air conditioner receiver works normally.

- If this remote control is intended to be not in use for a long time, please remove the batteries
- It may possibly caused internal program disorder if this remote control is not operated correctly, in case of that, please take out the battery, and install the batteries 35 minutes later, then the remote control may recover normal.

Applicable brand and code list

Brand	Code	Brand	Code	Brand	Code	Brand	Code	Brand	Code
ACSOM	980	DAOTIAN	821-824	HYUNDAI	780-789	PEREG	998	TADIAIR	501, 508, 509, 532
ADC	861	DELONGHI	990	INCYIN	475-483	PUNSHANGXINBAO	290	TADIRAN	501, 508, 509, 532, 630, 969, 978, 979, 991
AIDELONG	293-295	DUNAN	336	JIANGNAN	359	PILOT	902	TAIYA	862
AITE	296-299	DONGXIA	334-335	JIALE	358	PUYI	862	TCL	120-133
AKIRA	796-797	DONGXINBAO	260-268	JIMSTAR	360	QIXING	393	TEAC	850-859
AMCOR	501, 508, 509, 532, 973, 978, 979	ELCO	982	JINBEIJING	361-362	RAYBO	371-383	TECO	831-834
AMICO	982	ELECTER	981-986	JINDE	491-492	RHOSS	903	TIANYUNGTIAO	424
ALPIN	989-991, 998	ELECTROLUX	275, 376, 882	JINSONG	363-365	RICAI	394	TIANYUAN	425-428
AUCMA	210-22, 941	FEDDERS	878	JOHNSO	322	RUIJIAN	395-397	TOBO	250-269
AUX	180-199	FEIEDRICH	879	KANGLI	368-370	ROWA	383-385	TONGLI	429-430
AOKE	301-302	FEILU	240-249	KELONG	110-119	SACON	414	TOYO	825-828
AOLI	300	FERROLI	901	KONKA	366-367	SAMSUNG	610-629	TOSHIBA	630-639
APTON	862	FIRST	864	KRIS	804-805	SANYO NEC	500-530, 860, 943, 948	TRANE	812-816
BAIXUE	299	FRESTECH	270-279, 944-945	KT02-D001	283	SAPORO	861	UNI-AIR	368-369
BEIJINGJINGDIAN	304	FUJITSU	700-719	KT02-D002	284	SAST	450-452	UTTLEDUCK	454-556
BIG-THUMB	331	FUNIKI	992	KTY001	285	SENSOR	860	VIDEOCON	484
BLUESTAR	887	GALANZ	134-148, 936-940	KTY002	286	SERENE	499	WANBAO	431-433
BOERKA	630	GARRIER	690-699, 890-899	KTY003	287	SHAMEI	400	WANGZI	861
BOERKA	305-306	GEER	342-343	KTY004	288	SHANGLING	403-409	WEILI	434-443, 553-576
BOSHI	310	GLEE	280	KTY005	289	SHANYE	862	WEITELI	444
BOSHIGAO	308-309	GOLDSTAR	303	LG	600-609	SHANXING	401-402	WHIRLPOOL	770-774
BORLER	307	GREE	000, 020-039	LIANGYU	780	SHARP	720-739	WUFENG	445-446
CAIXING	311	GUANGDA	345-346	LIKEAIR	386-387	SHENBAO	410-411	XINGHE	462-463
CHANGFENG	190	GUQIAO	344	LITTLESWAN	453	SHENGFENG	412	XINLE	457-460
CHANGFU	835-838	HAIER	001-019	LONGHE	861	SHENGFENGFELIU	413	XILENG	448-449
CHANGLING	312-323	HELTON	863	LOREN-SEBO	801-803	SHINCO	200-209	XINLING	461
CHANGHONG	059-079, 934, 947	HEMILYON	095	MCCQUAY	790-795	SHINING	415	XIONGDI	862
CHENGYUAN	324	HICON	391-392	MIDEA	040-059	SHUANGLU	416-418, 946	YAIR	467-471, 044
CHIGO	080-099	HISENSE	230-239	MEILING	388-391	SIGMA	447	YAOMA	470, 977
CHUANGHUA	325-328	HITACHI	640-659	MINGXING_BOYIN	290	SOGO	291	YIDONG	499
CHUANYAN	861	HONGYI	347	MITSUBISHI	551-599	SONGLINXIA	862	YORK	775-779
COLROLLA	861	HUABAO	100-109	MITSUKA	904	SONGXING	419	YUTU	484-490
CHUNLAN	170-179	HUAGAO	348	NATIONAL Panasonic	660-689	SOVA	292	ZHONGYI	493-494
CONSUL	993	HUAKE	349-350	NIKKO	810-811	SOVA	420	ZHUODAN	495
CNROWA	337-341	HUAMEI	351-352	NISO	398-399	SOWA	862-863	YUETU	881-882, 949
CORONA	760-769	HUANGHE	353	NISO	497	SOYEA	421-422	DIY	044, 090, 092, 095
CROWN	861	HUALING	150-169, 045	NORCA	994	SPEED	987	OTHER	496, 498, 821-828, 839-849, 865-877, 905-976, 999
DAEWOO	332-333	HUAWEI	281	OLYMPUS	995-996	SRTC	423		
DAIKIN	740-759	HUIFENG	354-356	OPAL	997	STARIGHT-AIRCON	880		
DAJINXING	329-330	HUIFENG	357, 360	PANDA	464-466	SUNBORG	817-820		
DAKE	861								